

LivePremier Series supports both IPv4 and IPv6. This document summarizes all information needed for network administration.

IPv4 configuration

Addressing modes	Static / DHCP	
Default addressing mode	Static	
Default IP address	192.168.2.140	
Default Net Mask	255.255.255.0	
Gateway	None	
Opened ports	53	Domain Name Service (DNS) port Opened only if DHCP finds a DNS server
	80	Hypertext Transfer Protocol (HTTP) port For Web RCS and REST API
	10500	Analog Way proprietary port 1
	10506	Analog Way proprietary port 2
	10606	Analog Way JSON (AWJ) protocol port For external controllers
	10691	ControlBox JSON(CBJ) protocol port For RC400T
	21771	Secure Shell (SSH) port protected by a RSA key. No possible password

IPv6 configuration

Default IPv6 state	Disabled	
Addressing modes	Static or DHCP	
Default addressing mode	Static	
Default IP address	None	
Default Net Mask	FFFF:FFFF:FFFF:FFFF:0000:0000:0000:0000	
Gateway	None	
Opened ports	53	Domain Name Service (DNS) port Opened only if DHCP finds a DNS server
	80	Hypertext Transfer Protocol (HTTP) port. For WebRCS and REST API
	10500	Analog Way Proprietary port 1
	10606	Analog Way JSON (AWJ) protocol port For external controllers
	10691	Control Box JSON(CBJ) protocol port For RC400T
	21771	Secure Shell (SSH) port with RSA key encryption. No possible password

Average Consumed Bandwidth: 12MB/s

Analog Way Worldwide

Europe & Africa: +33 (0)1 81 89 08 60

Middle East: +971 4 25 33 818

The Americas: +1 212 269 1902

Asia Pacific: +852 6882 7140

www.analogway.com