

ANALOG WAY LIVEPREMIER™

Module: IMAGES

Crestron 3-series & 4-series

Date: **July 19th 2021**
Driver version: **V2.2.0**
Compatible with: **LivePremier™ Firmware V2.0.231 or above**

GENERAL

This module retrieves LivePremier™ still images status.

Control

General

AW_Img_RefreshInfos	Digital_in	Pulse this signal to force information retrieval. Most of the time this signal is never use
---------------------	------------	---

Status

AW_Img_Available_FB[X]	Digital_out	Equals 1 when still image X is available, 0 otherwise
AW_Img_Valid_FB[X]	Digital_out	Equals 1 if still image X is valid and can be used, 0 otherwise

In_Program

AW_Img_UsedInProgram_FB[X]	Digital_Out	Equals to 1 if still image X is being displayed in a Screen/Aux program
----------------------------	-------------	---

In_Preview

AW_Img_UsedInPreview_FB[X]	Digital_Out	Equals to 1 if still image X is being displayed in a Screen/Aux preview
----------------------------	-------------	---

Capabilities

AW_Img_OutOfCapabilities_FB[X]	Digital_Out	Equals to 1 if still image slot X is out of capacity
AW_Img_Capabilities_FB[X]	String_Out	The still image X defined capacity

Format

AW_Img_ImageWidth_FB[X]	Analog_Out	Still image X width in pixels
AW_Img_ImageHeight_FB[X]	Analog_Out	Still image X height in pixels
AW_Img_Format_FB[X]	String_Out	Still image X format: 'Width' x 'Height'

Label

AW_Img_Label_FB[X]	String_Out	Still image label
--------------------	------------	-------------------